

| <b>Cell-Phone Model</b>  | <b>Adapter #</b> |
|--|------------------|
| Apple iPhone   | 235              |
| Nokia 3000 & 8000 Series   | 213              |
| Blackberry Curve   | 235              |
| Blackberry 8300  | 235              |
| <b>The following LG models need Adapter #219:</b>  |                  |
| LG CE110   |                  |
| LG CU515   |                  |
| LG Dare  |                  |
| LG KE970 Shine   |                  |
| LG KG800 Chocolate   |                  |
| LG VX 8500 Chocolate   |                  |
| LG VX 8550 Chocolate   |                  |
| LG VU  |                  |
| <b>The following Samsung Models need Adapter #217:</b>   |                  |
| A437<br>A727<br>A737<br>Access,<br>ACE<br>Alias<br>Black Jack<br>Blast<br>Flip Shot<br>Glide<br>Instinct<br>Katalyst<br>SGH-N105<br>SGH-N625<br>SGH-P300<br>SGH-Q105<br>SGH-T229<br>SGH-T339<br>SPH-1330<br>Stripe |                  |
| All other Samsung models need Adapter #218   |                  |
| Sanyo Katana DLX 8500  | 235              |
| T-Mobile Sidekick  | 235              |